

DécorMark WallPapers allow bespoke printable wall decor applied using a clean and dry process.

DécorMark WallPaper Types

MD-W200 'Paste-the-wall' offers a cleaner application than traditional wallpapers and saves time when applying. As the paste can be applied directly to the wall, you don't need to soak the wallpaper, and the dry paper is easier to handle when applying.

MD-W300 'Pre-Pasted' also offers a cleaner application than traditional wallpapers and saves time when applying. The cut panels can be submerged in water which activates the paste allowing the paper to be applied directly. The special non-woven backing paper on each product doesn't expand when it gets wet so gives no shrinkage allowing a butt join without overlap.

1. Wall Preparation

- Remove imperfections and blemishes from the wall to achieve a smooth sound surface.
- Ensure that any filler or imperfections will be obscured by the opacity of the paper.
- Clean the surface with a sponge and warm water and then allow to dry.
- When applying to a newly plastered wall, or newly repaired wall, it is recommended to seal the walls in order to make sure all the moisture from the wallpaper paste isn't absorbed into the dry plaster.

2. Material Handling

- Ensure that the material has reached room temperature and a relative humidity of 50% before printing. Do not handle the face film directly before printing and ensure it is free from dust and static.

3. Printing Guidelines

- Ensure that the correct profiles and heater settings are used. Perform a test print first.
- When printing each panel, the best colour match will be achieved by alternating the orientation of each print to eliminate variance in colour across the printer width.
- Allow 24 hours after printing for the inks to fully dry. Take care with use of take up roller or stacking prints until fully cured.

4. Preparing the prints

- Non Woven WallPaper offers no shrinkage so can be applied with a butt join and no overlap.
- Pre-cut the graphic before fitting to give a finished graphic size ensuring perfect straight edges.

5. Preparing the Application

- Use a plumb line to mark the vertical drop of the first panel.
- Then mark the width of the first drop.
- Use solvent-free non-woven wallpaper paste.
- Allow excess on top, bottom and corners.

6. Application with MD-W200 Paste-the-wall

- Apply the paste to the wall, one section at a time. Paste with a 25mm bleed, so that the next drop can be applied without risk of adhesive onto the previous drop.

7. Application with MD-W300 Pre-Pasted WallPaper

- Get ready a water bath to soak the panels. Either use a tray to fit the roll into, or line the product box supplied with a polythene liner to create a watertight tray.
- Wet the backing by submerging the panels in water to activate the paste. When submerging, unwind the panels in the water to ensure activation of all the paste. Soak the panel for between 15-45 secs (45 secs max). Apply to the wall within 2 minutes. Change the water after every 6-7 drops.

8. Finishing the application

- Slide each panel to form a butt join with perfect registration of the graphic.
- Use a wallpaper brush to smooth down and to remove bubbles, so as not to mark the print.
- Use a damp cloth to remove any excess wallpaper paste from the media and surrounding surfaces.
- Trim the top, bottom and edges by running a blade down a tool or straight edge as a guide to track the wall.

9. Maintenance and Removal

- The graphic may be cleaned lightly with a damp non-abrasive soft sponge

MetaSure Warranty

The DécorMark range of wallcoverings is covered by our MetaSure warranty programme.

For data sheet and full warranty details please visit

www.metamark.co.uk/technical



For further technical support email technical@metamark.co.uk or call +44 (0)1483 571111

Metamark (UK) Limited

Luneside • New Quay Road • Lancaster • LA1 5QP • Tel +44 (0)1524 387140 • Fax +44 (0)1524 387147

Metamark House • Octimum Business Park • Forsyth Road • Woking • GU21 5SF • Tel +44 (0)1483 571111 • Fax +44 (0)1483 570540

sales@metamark.co.uk

www.metamark.co.uk